

# BRASS MINIMUM DIMENSION CHAMBER GAGES - L.E. WILSON 300 AAC BLACKOUT BRASS MINIMUM CHAMBER GAGE

[Reloading](#) > [Measuring Tools](#) > [Case Gauges & Headspace Tools](#)

Ever wonder if your reloads meet SAAMI minimum chamber dimensions? Then this is the gage for you. Min Dimensions Gages are made to SAAMI specifications for Min Chamber. SAAMI Min Chamber specs are slightly LARGER than Max Cartridge. The purpose of this gage is to check your reloaded rounds to see if they meet Min Chamber Specs. Therefore, if your rounds do not enter the Gage, then this is pointing to an issue with your reloaded round against SAAMI specifications. On the other hand, if your rounds DO enter the Gage, but DO NOT chamber in your gun. This points to you having a very tight chambered gun and would assume either an improperly cut reamer or a chamber that was cut below Min Chamber Dimension headspace. This does NOT mean that your round will not chamber in your specific gun's chamber. This only means the round DOES NOT meet SAAMI Min Chamber dimensions and is telling you to take another look before deciding that your round is good to fire.



## Attributes

- Name: [L.E. WILSON 300 AAC BLACKOUT BRASS MINIMUM CHAMBER GAGE](#)
- Manufacturer: [L.E. WILSON](#)
- Product no.: 749018709
- Mfr. No.: MDG-300B
- Cartridge: 300 AAC Blackout
- Delivery weight: 0.234kg
- Shipping height: 32mm
- Shipping width: 32mm
- Shipping length: 89mm
- UPC: 815145028686

## Item details

Made in USA

# Table of Contents

- [Startpage](#)
- [BRASS MINIMUM DIMENSION CHAMBER GAGES L.E. WILSON 300 AAC BLACKOUT](#)
- [About Us](#)

# **BRASS MINIMUM DIMENSION CHAMBER GAGES**

## **L.E. WILSON 300 AAC BLACKOUT**

### **Introduction**

Thank you for choosing the BRASS MINIMUM DIMENSION CHAMBER GAGE. This product is designed to help you ensure that your reloads meet the SAAMI minimum chamber dimensions. Proper use of this gage will assist you in identifying potential issues with your reloaded rounds, ensuring a safer reloading process.

### **General Safety Guidelines**

- Always handle the gage with care to avoid damage.
- Use the gage in a welllit area to ensure accurate measurements.
- Keep the gage out of reach of children and pets to prevent accidents.
- Regularly inspect the gage for any signs of wear or damage before use.
- If the gage is damaged, discontinue use and replace it.

### **Specific Safety Precautions for Use**

- Ensure that your firearm is unloaded before using the gage.
- Do not force a round into the gage. If it does not fit, it may indicate a problem with the round.
- If your reloaded round does not enter the gage, do not assume it is safe to fire. Investigate further to ensure compliance with SAAMI specifications.
- If the round fits the gage but does not chamber in your firearm, consult a qualified gunsmith to check your firearm's chamber dimensions.
- Always wear appropriate eye protection when reloading ammunition.

### **Instructions for Installation and Usage**

#### **1. Preparation:**

- Ensure your workspace is clean and organized.
- Gather your reloaded rounds and the gage.

#### **2. Using the Gage:**

- Insert the reloaded round into the gage.
- Check if the round fits into the gage:
  - If it fits: Proceed with caution. Verify that it chambers correctly in your firearm.
  - If it does not fit: This indicates a potential issue with the round. Do not attempt to fire it without further inspection.
- If the round fits the gage but does not chamber in your firearm, it may indicate a tight chamber. Consult a gunsmith for further evaluation.

#### **3. PostUse Care:**

- Clean the gage after use to remove any debris or residue.
- Store the gage in a safe, dry place away from direct sunlight and moisture.

### **Disposal Instructions**

- Dispose of any defective or damaged gages in accordance with local regulations.
- Do not throw away the gage in regular household waste. Check for local recycling options or hazardous

waste disposal facilities.

## **Contact Information for Further Support**

For any inquiries or concerns regarding the BRASS MINIMUM DIMENSION CHAMBER GAGE, please refer to the product packaging for details on obtaining support.

Thank you for your attention to these safety instructions. Your safety is our priority, and we hope you enjoy using the BRASS MINIMUM DIMENSION CHAMBER GAGE responsibly.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)