

BRASS MINIMUM DIMENSION CHAMBER GAGES - L.E. WILSON

6.5MM CREEDMOOR BRASS MINIMUM CHAMBER GAUGE

[Reloading](#) > [Measuring Tools](#) > [Case Gauges & Headspace Tools](#)

Ever wonder if your reloads meet SAAMI minimum chamber dimensions? Then this is the gage for you. Min Dimensions Gages are made to SAAMI specifications for Min Chamber. SAAMI Min Chamber specs are slightly LARGER than Max Cartridge. The purpose of this gage is to check your reloaded rounds to see if they meet Min Chamber Specs. Therefore, if your rounds do not enter the Gage, then this is pointing to an issue with your reloaded round against SAAMI specifications. On the other hand, if your rounds DO enter the Gage, but DO NOT chamber in your gun. This points to you having a very tight chambered gun and would assume either an improperly cut reamer or a chamber that was cut below Min Chamber Dimension headspace. This does NOT mean that your round will not chamber in your specific gun's chamber. This only means the round DOES NOT meet SAAMI Min Chamber dimensions and is telling you to take another look before deciding that your round is good to fire.



Attributes

- Name: [L.E. WILSON 6.5MM CREEDMOOR BRASS MINIMUM CHAMBER GAUGE](#)
- Manufacturer: [L.E. WILSON](#)
- Product no.: 749018713
- Mfr. No.: MDG-65CRE
- Cartridge: 6.5 Creedmoor
- Delivery weight: 0.277kg
- Shipping height: 32mm
- Shipping width: 38mm
- Shipping length: 89mm
- UPC: 815145028716

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for BRASS MINIMUM DIMENSION CHAMBER GAGES L.E. WILSON 6.5MM CREEDMOOR
- About Us

Safety Instruction Guide for BRASS MINIMUM DIMENSION CHAMBER GAGES L.E. WILSON 6.5MM CREEDMOOR

Introduction

Thank you for choosing the BRASS MINIMUM DIMENSION CHAMBER GAGES L.E. WILSON 6.5MM CREEDMOOR. This product is designed to help you ensure that your reloaded rounds meet the SAAMI minimum chamber dimensions. Proper use of this gauge is essential for safe and effective reloading practices. Please read this safety instruction guide carefully to understand how to use the product safely and effectively.

General Safety Guidelines

- Always handle the gauge with care to avoid damage.
- Ensure that the gauge is used in a welllit and clean environment.
- Keep the gauge out of reach of children and vulnerable individuals.
- Regularly inspect the gauge for wear and tear before use.
- Report any unsafe conditions or accidents to the appropriate authorities.
- Stay informed about product recalls and safety updates through the EU Safety Gate platform.

Specific Safety Precautions for Use

- Before using the gauge, ensure that your reloaded rounds are free from any obstructions or defects.
- If your rounds do not fit into the gauge, do not attempt to force them. This indicates a potential issue with the reloaded round.
- If the rounds fit into the gauge but do not chamber in your firearm, consult a qualified gunsmith to assess your firearm's chamber dimensions.
- Always wear appropriate safety gear, such as safety glasses, when handling ammunition and reloading equipment.
- Do not use the gauge for any purpose other than checking the dimensions of your reloaded rounds.

Instructions for Installation and Usage

1. Preparation

- Ensure that your workspace is clean and free from distractions.
- Gather your reloaded rounds and the gauge.

2. Using the Gauge

- Take one reloaded round and gently insert it into the gauge.
- Observe if the round fits into the gauge without resistance.
- If the round does not fit, it may not meet SAAMI minimum chamber dimensions.
- If the round fits but does not chamber in your firearm, consult a qualified gunsmith for further evaluation.

3. PostUsage Care

- After use, clean the gauge with a soft cloth to remove any debris or residue.
- Store the gauge in a safe place, away from moisture and extreme temperatures.

Disposal Instructions

- Dispose of any defective or unusable rounds according to local regulations.
- Do not throw the gauge in regular trash. Check with local waste management for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the BRASS MINIMUM DIMENSION CHAMBER GAGES L.E. WILSON 6.5MM CREEDMOOR, please refer to the product documentation or contact the manufacturer directly for assistance.

Thank you for your attention to these safety instructions. By following the guidelines provided, you can ensure safe and effective use of your gauge.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk