

1911 RECOIL SPRINGS - TACTICAL SPRINGS 16 LB. RECOIL SPRING

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Springs](#)

Consistent Performance For High-Stress, High-Volume Shooting

Premium-quality recoil spring helps ensure consistent, dependable operation for tens of thousands of compression cycles. Perfect for the high-volume tactical or competition shooter who needs a finely tuned spring that delivers its rated power as reliably on the 50,000th shot as it did on the first. Made from chromium-silicon steel alloy selected specifically for its hardness, heat resistance, and ability to withstand high stresses—the same alloy used for valve springs on automobile engines. Cryogenically treated to relieve internal stress, and surface impregnated with Sprinco's proprietary Plate+ molybdenum disulfide lubricating coating. Available in factory standard 16-lb. weight, as well as extra-power 17- and 18-lb. weights to reduce slide and frame battering with hot loads and shorten the distance spent brass is ejected from gun.



Attributes

- Name: [TACTICAL SPRINGS 16 LB. RECOIL SPRING](#)
- Manufacturer: [TACTICAL SPRINGS](#)
- Product no.: 943000013
- Mfr. No.: 25016
- Model: Government
- Pounds: 16 lbs
- Weapon type: 1911
- Delivery weight: 0.005kg
- Shipping height: 13mm
- Shipping width: 13mm
- Shipping length: 175mm
- UPC: 657780250165

Item details

Made in USA

Table of Contents

- Startpage
- 1911 Recoil Springs Safety Instruction Guide
- About Us

1911 Recoil Springs Safety Instruction Guide

Introduction

Thank you for choosing the 1911 Recoil Springs from Tactical Springs. This guide provides essential safety instructions and guidelines to ensure the safe use and maintenance of your recoil spring. Please read this document carefully before using the product to ensure a safe and effective experience.

General Safety Guidelines

- Ensure the product is used only as intended and in accordance with the manufacturer's instructions.
- Always handle firearms with care and follow all safety protocols associated with firearm use.
- Store the recoil spring in a safe, dry place away from heat sources and moisture.
- Inspect the recoil spring regularly for signs of wear or damage. Replace if any defects are found.
- Keep the product out of reach of children and unauthorized users.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Always verify that your firearm is unloaded before installation or maintenance.
- Wear appropriate eye protection when handling or installing the recoil spring.
- Use caution when working with compressed springs; they can cause injury if released suddenly.
- Do not exceed the recommended weight of the recoil spring for your specific firearm model.
- Ensure that all components of your firearm are compatible with the recoil spring being used.
- Follow the manufacturer's specifications for installation and usage to avoid malfunctions.

Instructions for Installation and Usage

Installation

1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools, including a punch tool and a screwdriver if needed.

2. Remove the Old Recoil Spring:

- Disassemble the firearm according to the manufacturer's instructions.
- Carefully remove the old recoil spring from the recoil spring guide.

3. Install the New Recoil Spring:

- Take the new 1911 recoil spring and align it with the recoil spring guide.
- Gently press the spring into place, ensuring it is seated correctly.

4. Reassemble the Firearm:

- Follow the manufacturer's instructions to reassemble the firearm.
- Ensure all parts are secure and properly aligned.

5. Test the Installation:

- Conduct a function check to ensure the firearm operates correctly with the new recoil spring.
- If any issues arise, disassemble and check the installation.

Usage

- Use the recoil spring only with compatible fullsize 1911 Auto Government Model firearms.
- Regularly maintain your firearm and inspect the recoil spring for any signs of wear or damage.
- If using higherpowered ammunition, consider utilizing the extrapower options (17 lb. or 18 lb.) to reduce slide and frame battering.

Disposal Instructions

- Dispose of the recoil spring in accordance with local regulations regarding metal waste.
- If the product is damaged or no longer usable, ensure it is disposed of in a manner that prevents accidental injury.

Contact Information for Further Support

For any questions or concerns regarding the 1911 Recoil Springs, please refer to the manufacturer's website or contact their customer service for assistance. Always ensure you have the latest information regarding safety recalls or updates through official channels.

Thank you for prioritizing safety and responsible use. Your adherence to these guidelines helps ensure a safe shooting experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk