

Ranger 1800 Laser Rangefinder

[Optics & Mounting](#) > [Rangefinders](#)

As its name indicates, the Vortex Ranger 1800 Rangefinder is capable of ranging targets with great precision out to 1800 yards - more than a mile! It gives hunters and long-range shooters the ranging data they need to make precise shots confidently, or to know when NOT to take the shot because the target is out of range. With its clean, uncluttered display and easy-to-use, intuitive menu, the Ranger 1800 keeps things simple, yet provides a high level of performance. Its Primary HCD (Horizontal Component Distance) mode displays an angle-compensated distance reading that boost your accuracy when shooting on uneven terrain. Or select LOS mode to get a reading of straight line-of-sight range. The Scan function displays continual range readings while tracking a moving animal or panning across a landscape. Neck lanyard & belt/pocket clip included Of course, the Ranger 1800 Rangefinder has Vortex's fully multi-coated, anti-reflective lenses that provide superb light transmission and a vivid, crisp image. Ideal for rifle hunters, target shooters, and bow hunters, the Ranger is sure to be a hit because it ensures hits.

NO IMAGE
AVAILABLE

Rubber "armor" on entire exterior provides a non-slip grip
O-ring sealed housing keeps moisture out & prevents fogging
Gives readings in yards or meters
HDC (angle compensated) & LOS (line of sight) ranging modes
Powered by a single CR-2 battery
Tripod adaptable

Attributes

- Name: [VORTEX OPTICS Ranger 1800 Laser Rangefinder](#)
- Manufacturer: [VORTEX OPTICS](#)
- Product no.: EU2003324
- Mfr. No.: RRF181
- Battery: CR2
- Color: Green
- Magnification: 6
- Objective Size: 22mm
- Range; Deer: 900 Yards
- Range; Reflective: 1800 Yards
- Weight: 7.7 oz
- Delivery weight: 0.454kg
- Shipping height: 102mm
- Shipping width: 76mm
- Shipping length: 127mm
- UPC: 875874009059

Item details

This product contains a battery.

Table of Contents

- [Startpage](#)
- [VORTEX OPTICS Ranger 1800 Laser Rangefinder Safety Instructions](#)
- [About Us](#)

VORTEX OPTICS Ranger 1800 Laser Rangefinder

Safety Instructions

Introduction

Thank you for choosing the VORTEX OPTICS Ranger 1800 Laser Rangefinder. This guide provides essential safety instructions to ensure the safe and effective use of your rangefinder. Please read this document carefully before using the product.

General Safety Guidelines

- Ensure the product is used only for its intended purpose.
- Keep the rangefinder out of reach of children and vulnerable individuals.
- Do not use the rangefinder in adverse weather conditions, such as heavy rain or snow, unless it is specifically designed for such use.
- Regularly check for any signs of damage or wear on the device. If damaged, do not use the rangefinder until it has been repaired.
- Avoid looking directly into the laser beam. The laser emitted by this device can cause eye damage.
- Follow all local laws and regulations regarding the use of laser rangefinders.

Specific Safety Precautions for Use

- Always use the rangefinder in accordance with the manufacturer's instructions.
- Do not disassemble or modify the rangefinder. This may result in malfunction or safety hazards.
- Ensure that the battery is installed correctly and is not leaking. Replace with the specified CR2 battery only.
- When using the rangefinder, maintain a safe distance from the target to avoid any potential accidents.
- If using the rangefinder in a hunting or shooting environment, ensure that all safety measures related to firearms are strictly followed.

Instructions for Installation and Usage

1. Battery Installation:

- Open the battery compartment by sliding the cover in the direction indicated.
- Insert a new CR2 battery, ensuring that the positive (+) and negative (-) terminals are correctly aligned.
- Close the battery compartment securely.

2. Operating the Rangefinder:

- Press the power button to turn on the device.
- Select the desired mode (HCD or LOS) using the menu button.
- Aim the rangefinder at the target and press the measurement button to obtain the distance reading.
- For continuous readings, activate the Scan function.

3. Care and Maintenance:

- Clean the lenses with a soft, lintfree cloth. Avoid using harsh chemicals or abrasive materials.
- Store the rangefinder in a cool, dry place when not in use.
- Use the included neck lanyard or belt/pocket clip to prevent accidental drops.

Disposal Instructions

- Dispose of the rangefinder and its components in accordance with local regulations regarding electronic waste.
- Do not dispose of batteries in regular household waste. Follow local guidelines for battery disposal or recycling.

Contact Information for Further Support

For any questions or concerns regarding the safety or functionality of the VORTEX OPTICS Ranger 1800 Laser Rangefinder, please refer to the manufacturer's contact information included in the product packaging or on the official website.

Thank you for your attention to these safety instructions. Enjoy the precision and performance of your new VORTEX OPTICS Ranger 1800 Laser Rangefinder!

About Us

Brownells Česká republika

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.cz